

# Application Instruction For



## Contact Information

www.irononsticker.com

Tel:647-499-7651

Address: 8-91 Esna Park Drive,  
Markham Ontario L3R2S2, Canada

Email: irononsticker@gmail.com

# PRINTABLE HEAT TRANSFER MATERIAL

## Instructions by home iron:

We offer 6 standard sizes, namely, 2 inches, 4 inches, 6 inches, 8 inches, 10 inches, 12 inches for our customers, of course, any sizes (not larger than 18 inches) and any images are accepted.

How to iron iron-on sticker on fabric with a home iron?

Temperature: maximum, time: 1-2 minutes, pressure: firmly and evenly

**Step 1:** Find a hard surface that is waist-high or lower, ironing boards are not recommended.



Step 1: Find a hard surface that is waist-high or lower, ironing boards are not recommended.

**Step 2:** Set your home iron to its maximum temperature and no steam.



Step 2: Set your home iron to its maximum temperature and no steam

**Step 3:** Pre-heat your shirts to get rid of any wrinkles for 10-60 seconds before start, remove the bottom protection cover (or grease proof paper), and position iron-on sticker on fabric.



Step 3: Pre-heat your shirts to get rid of any wrinkles before start



remove the bottom protection cover (or grease proof paper)

**Step 4:** Cover iron-on sticker with the grease proof paper or cloth.



Step 4: Place the grease proof paper or cloth to the top of the sticker

**Step 5:** heat apply it firmly and evenly with home iron for 1-2 minutes, the time depends on iron-on stickers' size. For big graphic stickers, keep moving home iron from one way to the other way (as "red arrow" in the picture below shows) and do not move iron in the other way around because that may create wrinkles.



Step 5: Using firm pressure to press the heat transfer, keep 1-2 minutes, the press time depending on the logo size



## SHOW

Step 7: finished



Finished

**Step 6:** Remove the grease proof paper, while still hot, and slowly peel off top mask from the images, too



Remove the grease proof paper, while still hot, and slowly peel off top mask from the images, too

### • Tip

A Heat Printing Pillow or Print Perfect Pad is recommended for even pressure when working around zippers, buttons, heavy seams or mesh reversible jerseys.

All technical information and recommendations are based on tests we believe to be reliable. However, we cannot guarantee performance for conditions not under manufacturer's control. Before using, please determine the suitability of product for its intended use. The user assumes all risk and liability whatsoever in connection with the use of this product. Seller's and manufacturer's only obligation shall be to replace such quantity of the product proved to be defective by manufacturer.

© irononsticker' ID Direct™ 2011 - All International Rights Reserved

### • Recommended Fabrics

Cotton, Polyester, Poly/cotton blends, Lycra/ Spandex blends, Woven nylon, Nylon knits, Nylon meshes - micro, tricot, mini, reversible, Polyester knits, Polyester mesh, Sublimated Polyester, Poly/foam & cotton caps, Satin, Cordura

### • Care Instructions

For best results, turn garment insideout. Machine wash warm or cold using mild detergent. Do not bleach. Do not iron directly on transfer. Tumble dry low setting. Do not dry clean